






SKU : AS-0210	Name : KL rock slider	Truck Model : Jeep KL
---------------	-----------------------	-----------------------




Instruction manual for installation KL rock slider

List of components provided in the kit	List of tools needed for installation
<ul style="list-style-type: none">• 20 x 1/4" Flat stainless washers• 40 x 1/4" Flat washers• 20 x 1/4" Nylon nuts• 20 x 1/4" Nutserts• 20 x 1/4" – 20 UNC x 3/4" Button head stainless bolts• 20 x 1/4" – 20 UNC x 1" Bolts	<ul style="list-style-type: none">• Drill• 3/8" Drill bit• 9/32" Drill bit (recommend cobalt drill bit)• Nutsert tool puller• 5/32" Allen key• 7/16" Wrench• 7/16" Socket


Instructions to assemble the sliders under your Jeep.

1	Remove the Original Equipment Manufacturer on plastic footboard stock.	
2	Cut the little plastic left under the front fender with a knife to be able to place the FrogFab rock slider.	
3	Redrill the 20 holes to 3/8" for nutsert where the OEM footboard clips were fixed. Redrill the holes for boat side off the Jeep. (see picture for front door and do the same for back door)	

SKU : AS-0210	Name : KL rock slider	Truck Model : Jeep KL
---------------	-----------------------	-----------------------

4	Install 10 nutserts on each side of the Jeep with nutsert tool puller. (see picture for front door and do the same for back door)	
5	Install the two sliders just with two 1/4" – 20 UNC x 3/4" button head stainless bolts on the top front door and back door brackets of the sliders. Then place them correctly to make marks to drill the lower holes after.	
6	Remove the two sliders.	
7	Drill 8 holes in the body with a 9/32" drill bit where you made the marks. (We recommend the use of a good cobalt drill bit for better and easier results)	

SKU : AS-0210	Name : KL rock slider	Truck Model : Jeep KL
---------------	-----------------------	-----------------------

8	Assemble the two sliders with twenty 1/4" – 20 UNC x 3/4" button head stainless bolts with twenty 1/4" flat stainless washers on the top front and back brackets of the sliders.	
9	Put twenty 1/4" – 20 UNC x 1" bolts with forty 1/4" flat washers and twenty 1/4" nylon nuts through the FrogFab sliders and the body and tighten all the bolts. (One washer on each side)	